

2019 BMW X2 xDrive 28i AWD (F39) L4-2.0L Turbo (B46O)

Vehicle > Engine, Cooling and Exhaust > Engine > Engine Lubrication > Service and Repair > Procedures

RELEASING THE OIL DRAIN PLUG [REP-TAT-P-1113-01-F46_B38]

Releasing the oil drain plug


REP-TAT-P-1113-01-F46_B38

 WARNING

- Hot fluids.
- Risk of scalding!
- Conduct all work in the vehicle wearing appropriate personal protective equipment only.

 TECHNICAL INFORMATION

Collect and dispose of emerging fluids. Observe country-specific waste disposal regulations.



- Release oil drain plug (1).
- Allow the motor oil to drain out fully.

BMW Engine Oil Service Without Supplementary Service		
Back To Step 2	Step 3 of 14	Go To Step 4