

2019 BMW 330i Sedan (G20) L4-2.0L Turbo (B46D)

Vehicle > Engine, Cooling and Exhaust > Engine > Engine Lubrication > Engine Oil > Service and Repair > Procedures

RELEASING THE OIL DRAIN PLUG [REP-TAT-P-1113-01-6]

Releasing the oil drain plug


REP-TAT-P-1113-01-6

 WARNING


Hot fluids.

Risk of scalding!

- Conduct all work in the vehicle wearing appropriate personal protective equipment only.



- Turn and remove service cap (1).



- Open oil drain plug (1) from the oil sump.

 TECHNICAL INFORMATION

Collect and dispose of emerging fluids. Observe country-specific waste disposal regulations.

- Allow the motor oil to drain out fully.

Engine Oil Service		
Back To Step 3	Step 4 of 13	Go To Step 5